

How To: A Step-by-Step Guide

ASSEMBLY STEPS (For unassembled frames only)

- 1) Lay frame pieces face down on a padded, flat surface.
- 2) Apply moderate amount of glue to end of one piece of frame.
- 3) Align adjoining frame piece to glued end.
- 4) Press corner connectors into slots until flush with back of frame. (Tap lightly with hammer if necessary)
- 5) Repeat steps 1-4 on all four corners.
- 6) Flip frame over and adjust if necessary.
- 7) Wipe off any excess glue with damp rag.
- 8) Allow at least 1 hour dry time for best results.

INSTALLATION STEPS

- 1) Remove tape backing from cardboard alignment corners only.
- 2) Hold frame up to desired position on mirror. (May take two people)
- 3) Apply alignment corners to mirror inside both upper corners of frame. (Place third support corner under upper middle of frame if provided)
- 4) Remove and adjust alignment corners if necessary until frame is in desired position. (Peel off corners slowly. Using a hair dryer will help make removal of corners much easier)
- 5) Carefully remove frame from mirror.
- 6) Remove tape backing from back of frame. (Do not allow anything to touch tape once backing is removed, as it is permanent)
- 7) Carefully lift frame and rest on alignment corners **without allowing tape to touch mirror!**
- 8) Starting at the top, slowly press frame against mirror, and then firmly press along entire length of frame.
- 9) Remove the alignment corners from mirror and you're done!
- 10) Show your friends and family what an amazing transformation your room has undergone!

A huge THANK YOU from your friends at Mirror Makeover!